



Fix box to a flat hard surface. Make sure the control cable spade terminals are correctly fitted in the contactor terminals. Take care not to damage the contactor terminals. Make sure that all terminals are tight including factory fitted terminals that may have worked loose during transit. Fit the PRE9230 in a 25mm back box or greater. The supply and return cables need to be mechanically protected.

