



Ensure the maximum rated load is not exceeded. Ensure That all electrical connections are fully tightened including factory fitted connections which may have worked loose during transit.

